


Scansku Scanners Gesture Setting

When using the Webatar and swiping left and right you may find some conflict with swipe actions used in Webatar apps. Accidental swipes might trigger unintended actions.

To fix this please follow the below steps:

1. **Open Settings**
Swipe up from the home screen and tap the **Settings** app.
2. **Navigate to System Settings**
Scroll down and tap **System**.
3. **Tap on Gestures**
Inside System, select **Gestures**.
4. **Choose System Navigation**
Tap **System navigation**.
5. **Select 3-Button Navigation**
Choose the **3-button navigation** option.

Your screen will now show the classic Back, Home, and Recent buttons at the bottom within the Webatar App as well.



Revision #2

Created 3 September 2025 23:16:30 by Pamela

Updated 3 September 2025 23:26:17 by Pamela